


PR relays

Complete relay part number breakdown



PR1 Series							
SPDT							
Part number	Part description	Termination type	Max switching current	Base	Relay	Protection module	Bracket
2834326	PR1-RSC3-LDP-24DC/21	Screw	12 A	2833521	2961312	2833657	2833547
2834339	PR1-RSC3-LV-24AC/21	Screw	12 A	2833521	2961406	2833712	2833547
2834342	PR1-RSC3-LV-120AC/21	Screw	12 A	2833521	2961419	2833738	2833547
2834355	PR1-RSC3-LV-230AC/21	Screw	12 A	2833521	2961422	2833738	2833547
2834407	PR1-RSP3-LDP-24DC/21	Spring	12 A	2833534	2961312	2833657	2833547
2834410	PR1-RSP3-LV-24AC/21	Spring	12 A	2833534	2961406	2833712	2833547
2834423	PR1-RSP3-LV-120AC/21	Spring	12 A	2833534	2961419	2833738	2833547
2834436	PR1-RSP3-LV-230AC/21	Spring	12 A	2833534	2961422	2833738	2833547


SPDT with gold contacts							
Part number	Part description	Termination type	Max switching current	Base	Relay	Protection module	Bracket
2834368	PR1-RSC3-LDP-24DC/21AU	Screw	50 mA	2833521	2961545	2833657	2833547
2834371	PR1-RSC3-LV-24AC/21AU	Screw	50 mA	2833521	2961503	2833712	2833547
2834384	PR1-RSC3-LV-120AC/21AU	Screw	50 mA	2833521	2961516	2833738	2833547
2834397	PR1-RSC3-LV-230AC/21AU	Screw	50 mA	2833521	2961529	2833738	2833547
2834449	PR1-RSP3-LDP-24DC/21AU	Spring	50 mA	2833534	2961545	2833657	2833547
2834452	PR1-RSP3-LV-24AC/21AU	Spring	50 mA	2833534	2961503	2833712	2833547
2834465	PR1-RSP3-LV-120AC/21AU	Spring	50 mA	2833534	2961516	2833738	2833547
2834478	PR1-RSP3-LV-230AC/21AU	Spring	50 mA	2833534	2961529	2833738	2833547

DPDT							
Part number	Part description	Termination type	Max switching current	Base	Relay	Protection module	Bracket
2834481	PR1-RSC3-LDP-24DC/2X21	Screw	8 A	2833521	2961192	2833657	2833547
2834494	PR1-RSC3-LV-24AC/2X21	Screw	8 A	2833521	2961435	2833712	2833547
2834504	PR1-RSC3-LV-120AC/2X21	Screw	8 A	2833521	2961448	2833738	2833547
2834517	PR1-RSC3-LV-230AC/2X21	Screw	8 A	2833521	2961451	2833738	2833547
2834562	PR1-RSP3-LDP-24DC/2X21	Spring	8 A	2833534	2961192	2833657	2833547
2834575	PR1-RSP3-LV-24AC/2X21	Spring	8 A	2833534	2961435	2833712	2833547
2834588	PR1-RSP3-LV-120AC/2X21	Spring	8 A	2833534	2961448	2833738	2833547
2834591	PR1-RSP3-LV-230AC/2X21	Spring	8 A	2833534	2961451	2833738	2833547

DPDT with gold contacts							
Part number	Part description	Termination type	Max switching current	Base	Relay	Protection module	Bracket
2834520	PR1-RSC3-LDP-24DC/2X21AU	Screw	50 mA	2833521	2961215	2833657	2833547
2834533	PR1-RSC3-LV-24AC/2X21AU	Screw	50 mA	2833521	2961464	2833712	2833547
2834546	PR1-RSC3-LV-120AC/2X21AU	Screw	50 mA	2833521	2961477	2833738	2833547
2834559	PR1-RSC3-LV-230AC/2X21AU	Screw	50 mA	2833521	2961480	2833738	2833547
2834601	PR1-RSP3-LDP-24DC/2X21AU	Spring	50 mA	2833534	2961215	2833657	2833547
2834614	PR1-RSP3-LV-24AC/2X21AU	Spring	50 mA	2833534	2961464	2833712	2833547
2834627	PR1-RSP3-LV-120AC/2X21AU	Spring	50 mA	2833534	2961477	2833738	2833547
2834630	PR1-RSP3-LV-230AC/2X21AU	Spring	50 mA	2833534	2961480	2833738	2833547

PR relays

Complete relay part number breakdown



PR2 Series							
DPDT							
Part number	Part description	Termination type	Max switching current	Base	Relay	Protection module	Bracket
2834643	PR2-RSC3-LDP-24DC/2X21	Screw	10 A	2833576	2834025	-	2833592
2834656	PR2-RSC3-LV-24AC/2X21	Screw	10 A	2833576	2834054	2833864	2833592
2834669	PR2-RSC3-LV-120AC/2X21	Screw	10 A	2833576	2834067	2833880	2833592
2834672	PR2-RSC3-LV-230AC/2X21	Screw	10 A	2833576	2834070	2833880	2833592
2834685	PR2-RSP3-LDP-24DC/2X21	Spring	10 A	2833589	2834025	-	2833592
2834698	PR2-RSP3-LV-24AC/2X21	Spring	10 A	2833589	2834054	2833864	2833592
2834708	PR2-RSP3-LV-120AC/2X21	Spring	10 A	2833589	2834067	2833880	2833592
2834711	PR2-RSP3-LV-230AC/2X21	Spring	10 A	2833589	2834070	2833880	2833592

SPDT with gold contacts							
Part number	Part description	Termination type	Max switching current	Base	Relay	Protection module	Bracket
2834724	PR2-RSC3-LDP-24DC/4X21AU	Screw	5 A	2833576	2834096	-	2833592
2834737	PR2-RSC3-LV-24AC/4X21AU	Screw	5 A	2833576	2834122	2833864	2833592
2834740	PR2-RSC3-LV-120AC/4X21AU	Screw	5 A	2833576	2834135	2833880	2833592
2834753	PR2-RSC3-LV-230AC/4X21AU	Screw	5 A	2833576	2834148	2833880	2833592
2834766	PR2-RSP3-LDP-24DC/4X21AU	Spring	5 A	2833589	2834096	-	2833592
2834779	PR2-RSP3-LV-24AC/4X21AU	Spring	5 A	2833589	2834122	2833864	2833592
2834782	PR2-RSP3-LV-120AC/4X21AU	Spring	5 A	2833589	2834135	2833880	2833592
2834795	PR2-RSP3-LV-230AC/4X21AU	Spring	5 A	2833589	2834148	2833880	2833592